

VIT cam – Hi-G lights for on-board applications

Hi-G lights for on-board Applications

On-board tests in automotive and other vehicle test applications need often also on-board illumination for optimized results.

Size is another subject for on-board illumination. On many tests, space for lights is very limited. The ultra compact size of the VITlight makes it ideal for these mounting attitudes:

- foot and pedal area
- under-seat mountings
- close-up shots of interior details
- under-hood mountings

Product features of VIT light:

Compact size

140 x 60 x 60mm and lightweight

Rugged design

To withstand impacts of up to 100G (excl. bulb)

Robust

Solid aluminium housing

Easy to install

Standard tripod threads (1/4" and 3/8") plus M6 threads

Standard supply voltage

No special power supply necessary. (12/15/24VDC, other voltages on request)



Product specifications:

Size:	140 x 60 x 60mm
Weight:	0.38 kg
Supply power:	24VDC
Bulbs:	XENOPHOT type
Power rating:	50...250W subject to bulb type selected

Note

Bulbs are not ruggedized and need to be replaced after each Hi-G impact



Imaging for smart decisions