



*Lens for illustration purpose only; not included
Objektiv nur zur Illustration; nicht inbegriffen*

PRODUCT LEAFLET

CMT lens adapter

Lens adapter with manual iris ring for F-mount lenses

Application

New high speed cameras with high image resolution / large image sensors need suitable lenses with a large image diameter to avoid vignetting.

Lenses made for DSLR-cameras would be an ideal fit (wide selection, wide zooming range, inexpensive, easily available), however most of those lenses have no iris ring anymore to manually step down the aperture.

The CMT lens adapter features a mechanical iris ring to set the lens aperture to any desired value.

The CMT accepts lenses with an F-mount and a mechanical aperture lever.

Use NIKON DX- and FX-lenses, or similar lenses made by 3rd party suppliers like SIGMA, TAMRON or TOKINA (brand names are used for reference purpose only).

The lens/adapter combination fits all AOS high speed cameras, as well as many high speed- and vision cameras equipped with a c-mount of other manufacturers.

Available exclusively by:

AOS Technologies AG, Taefernstrasse 20, CH-5405 Baden-Daettwil, info@aostechnologies.com, www.aostechnologies.com

CMT Objektiv Adapter

Objektivadapter mit manueller Blendenvorwahl für Objektive mit F-Bajonett

Anwendung

Moderne Hochgeschwindigkeitskameras mit hoher Auflösung / grossen Bildsensoren benötigen passende Objektive mit grossem Bildkreis zur Vermeidung von störender Vignettierung.

Objektive für DSLR-Kameras wären ideal (grosse Auswahl, grosser Zoombereich, preisgünstig, hohe Verfügbarkeit), jedoch fehlt bei den meisten ein Abblendring zur Blendenwahl.

Der CMT Objektiv Adapter weist einen manuellen Blendenring auf und erlaubt die Wahl jeder gewünschten Blendenöffnung.

Der CMT Objektiv Adapter gestattet die Verwendung von Objektiven mit F-Bajonett und mechanischem Abblendhebel.

Passend sind NIKON DX- und FX-Objektive, wie auch vergleichbare Objektive von Fremdherstellern wie SIGMA, TAMRON oder TOKINA (die genannten Markennamen dienen ausschliesslich der technischen Erläuterung).

Die Objektiv-/Adapter-Kombination passt an alle AOS Hochgeschwindigkeitskameras, wie auch an viele Hochgeschwindigkeits- und Vision Kameras mit c-mount Anschluss anderer Hersteller.

Exklusiv erhältlich bei: